

Steps:

1. insert an USB stick on the altitude
2. export all to an USB stick
3. eject USB stick
4. put the USB stick on a laptop
5. put the procella PEQ folder content here as below.
6. put the USB stickback on the Altitude
7. import PEQ

