



# DA08-DSP

Pre-Set V1.1

		SPEAKER EQ				INPUT				OUTPUT			
		Ch1	Ch2	Ch3	Ch4	Ch1	Ch2	Ch3	Ch4	Ch1	Ch2	Ch3	Ch4
Preset 1	4x Flat, No Eq	Pass Through	Pass Through	Pass Through	Pass Through	Ch1	Ch2	Ch3	Ch4	Ch1	Ch2	Ch3	Ch4
Preset 2	2x P5-P28 and P15	P5-P28 in BW	P5-P28 in BW	P15 Wall	P15 Wall	P5-P28 (1)	P5-P28 (2)	P15	-	P5-P28 (1)	P5-P28 (2)	P15 Drv 1	P15 Drv 2
Preset 3	2x P5-P28 and P18	P5-P28 in BW	P5-P28 in BW	P18 in BW	P18 in BW	P5-P28 (1)	P5-P28 (2)	P18	-	P5-P28 (1)	P5-P28 (2)	P18 Drv 1	P18 Drv 2
Preset 4	2x P610	P610 Lo	P610 Hi	P610 Lo	P610 Hi	P610 (1)	-	P610 (2)	-	P610 LF (1)	P610 HF (1)	P610 LF (2)	P610 HF (2)
Preset 5	P610 and P15	P610 Lo	P610 Hi	P15 Wall	P15 Wall	P610	-	P15	-	P610 LF (1)	P610 HF (1)	P15 Drv 1	P15 Drv 2
Preset 6	2x P815	P815 Lo	P815 Hi	P815 Lo	P815 Hi	P815 (1)	-	P815 (2)	-	P815 LF (1)	P815 HF (2)	P815 LF (1)	P815 HF (2)
Preset 7	P815 and P18	P815 Lo	P815 Hi	P18 in BW	P18 in BW	P815	-	P18	-	P815 LF (1)	P815 HF (2)	P18 Drv 1	P18 Drv 2
Preset 8	2x P880	P880 Lo in BW	P880 Hi	P880 Lo	P880 Hi	P880 (1)	-	P880 (2)	-	P880 LF (1)	P880 HF (1)	P880 LF (2)	P880 HF (2)
Preset 9	P880 and V18	P880 Lo	P880 Hi	V18	V18	P880	-	V18	-	P880 LF (1)	P880 HF (1)	V18 Drv 1	V18 Drv 2
Preset 10	P880 and V21	P880 Lo	P880 Hi	V21	V21	P880	-	V21	-	P880 LF (1)	P880 HF (1)	V21 Drv 1	V21 Drv 2
Preset 11	2x P15	P15 Wall	P15 Wall	P15 Wall	P15 Wall	P15	-	P15	-	P15 Drv 1 (1)	P15 Drv 2 (1)	P15 Drv 1 (2)	P15 Drv 2 (2)
Preset 12	2x P18	P18 in BW	P18 in BW	P18 in BW	P18 in BW	P18	-	P18	-	P18 Drv 1 (1)	P18 Drv 2 (1)	P18 Drv 1 (2)	P18 Drv 2 (2)
Preset 13	2x V18	V18 (1)	V18 (2)	V18 (1)	V18 (2)	V18	-	V18	-	V18 Drv 1 (1)	V18 Drv 2 (1)	V18 Drv 1 (2)	V18 Drv 2 (2)
Preset 14	V21	V21 (Bridged)		V21 (Bridged)		V21	-	-	-	V21 Drv 1	-	V21 Drv 2	-